

THE POWER OF  
**REDARC**®

**TOW PRO WIRING KITS**



PART #	DESCRIPTION
TPWKIT-012	Ford Ranger Wiring Kit
TPWKIT-013	Universal Tow-Pro Wiring Kit
TPWKIT-014	Universal Tow-Pro Extended Wiring Kit

- FEATURES:**
- Simple to install
  - Reduces fitment time
  - Includes everything required to support the installation of a tow pro
  - Includes fitting instructions
  - Protects vehicle from incorrect wiring

REDARC has released a simplified range of Tow-Pro Wiring Kits supporting the installation of the market-leading Tow-Pro Elite electric trailer brake controller into a wide range of vehicles. By streamlining the range from 10 to 3 kits, customers can simplify their stockholding.

For each of the 3 kits, the interface to the vehicle stop lamp signal is made at the trailer socket; this provides a consistent reliable source of the 12V signal indicating when trailer braking is required, and supports modern driver aids such as Autonomous Emergency Braking; Adaptive Cruise Control and collision avoidance where the vehicle brake signal may be generated from a number of different systems.

One of the three kits is unchanged - TPWKIT-012 - supporting Ford Ranger and Everest. The other two kits differ only in the provision of the length of the positive power connection.

In all 3 TPWKIT's, hardware and fitting instructions are included to deliver a quality and reliable outcome every time whilst protecting the integrity of the vehicle, avoiding the setting of fault codes or damage to sensitive electronics.

OLD PART #	VEHICLE	NEW PART #
TPWKIT-002	Colorado	TPWKIT-013
TPWKIT-003	Triton	TPWKIT-014
TPWKIT-004	Hilux	TPWKIT-013
	Fortuner	TPWKIT-013
	Prado	TPWKIT-013
TPWKIT-005	LC200	TPWKIT-014
TPWKIT-006	Isuzu	TPWKIT-013
TPWKIT-007	Kluger	TPWKIT-013
TPWKIT-008	Navara	TPWKIT-014
TPWKIT-009	Pajero	TPWKIT-013
TPWKIT-010	Amarok	TPWKIT-014
TPWKIT-011	Universal	TPWKIT-014
TPWKIT-012	Ranger/Everest	TPWKIT-012

